



SETTING UP A TOTAL STATION

①




BRING THE OPTICAL
PLUMB INTO THE POINT
USING THE FEETSCREWS

②




LEVEL THE CIRCULAR
BUBBLE USING THE
TRIPOD LEGS
MAKE SURE THE TRIPOD
FEET DO NOT MOVE.

③



LEVEL THE INSTRUMENT
USING THE ~~LEVEL~~ PLATE
BUBBLE

④



SLACKEN THE
INSTRUMENT SCREW
MOVE INSTRUMENT ON
TRIPOD SO THAT OPTICAL
PLUMB IS ON THE POINT

CHECK 3 + 4 AGAIN