

## How to access the notes taken during measurements in X-PAD

**Notebook:** Xpad  
**Created:** 01/04/2021 14:11 **Updated:** 16/06/2021 19:48  
**Author:** Service Hitechniques  
**Tags:** Note

---

## How to access the notes taken during measurements in X-PAD

Created: 20210401\_DL

There are two types of notes:

- Automatic notes: Notes inserted automatically by the software in response to certain events as:
  - connection of the instrument
  - interruption of the connection of the instrument
  - start of recording of raw data
  - start of the base
  - interruption of recording of raw data
- User notes: texts, sketches and photo saved by the user

To see saved notes follow the steps: Navigate to main menu > Job tab > Points/Measurement/Codes > Measurements tab > Tools > View Notes