



Laserliner

DistanceMaster Vision



Laser distance meter – with camera function

Rev18W12



- **Point-precise measuring with laser** to determine lengths exactly
- **Camera function** with 8x digital zoom
- **Min/Max function** to determine diagonals, verticals and horizontals
- **The area and volume functions** permit the acquisition of room sizes, for example to calculate material quantities
- **Pythagoras measurement function and angle function**
- **360° inclination sensor** for determining the horizontal and vertical distance
- Simple assessment of room perimeter with the **addition and subtraction functions**
- The **wall surface function** automatically adds up surfaces by measuring the lengths of walls as well as their height once.
- **Stake out function** for marking off defined lengths
- **Digital bubble level** to align the measuring device
- **High measuring accuracy** up to 80 m: $\pm 2 \text{ mm}^*$
- **4 selectable measurement reference points:** front, tripod, rear and pin
- 1/4" tripod connection
- Interface to charge the NiMH batteries
- Illuminated colour LCD
- Internal measured value memory

TECHNICAL DATA

ACCURACY $\pm 2 \text{ mm}$ (typical)*
MEASUREMENT RANGE max. 80 m
MINIMAL RANGE 0,05 m
LASER Class 2 < 1mW
LASER WAVELENGTH 635 nm
OPERATING CONDITIONS 0°C ... 40°C
STORAGE CONDITIONS -20°C ... 60°C
UNIT (selectable) m / ft / '"/inch
FUNCTIONS distances, continuous measurement, areas, volumes, addition, subtraction function, wall surface function, angle function 1**, Pythagoras 1 + 2 + 3, digital bubble level, 360° inclination sensor, stake out function
POWER SUPPLY Rechargeable batteries 3x NiMH, type AAA
DIMENSIONS (W x H x D) 59 x 136 x 29 mm
WEIGHT with batteries 172 g

* See operating instructions for specific accuracies
** In combination with 360° inclination sensor



DistanceMaster Vision

- inclusive carrying case
- + rechargeable batteries (3 x NiMH type, AAA)
- + softbag
- + USB cable

Packaging dimension (W x H x D)
155 x 265 x 81 mm



Viewfinder to target the measurement area



Folding pin for measurements out of a corner



Timer function to automatically trigger measurement

ARTICLE	ARTICLE NO	EAN-CODE	PU
DistanceMaster Vision	080.980A	4 021563 703661	5

